
INTRODUCTION

Engine Compartment Fuse Box



Link	Rating	Wire Colour	Function
1	30 Amp	N	Lighting switch, dim dip resistor, BBUS, alarm sounder relay, anti-theft alarm LED, fuse 21.
2	60 Amp	N	Ignition switch, starter relay, fuses 1 and 2.
3	60 Amp	N	Glow plug timer.
4	20 Amp	N	Heated rear screen relay, fuses 18 and 19 (non A/C vehicles only).
4	60 Amp	N	Heated rear screen relay, main A/C, fuses 18 and 19.